


English

Version 1.22(December 2018)

- The Jetibox Profi supports the receivers Duplex Rex Assist; Telemetry from receiver displays correctly.
- The RC DroidBox is supported; The RC Droid Box could be connected to Jetibox Profi via Ji connector. The telemetry from Jetibox Profi is sent to RC DroidBox / smartphone.

How to activate EX output and connecting RC DroidBox to Jetibox Profi

- Switch-on the JETIBOX Profi



- Push ESC: Main menu, select item SET-UP, confirm by ENTER




- Select item MAIN, confirm by ENTER



- Select item Ji mode and change it to EX output



RC DroidBox connection



Version 1.21 (July 2018)

- This version solves the problem of missing telemetry values which could appear in some cases.


Česky

Verze 1.22 (Prosinec 2018)

- Podpora přijímačů Duplex Rex Assist; Korektní zobrazení telemetrie přijímačů
- Podpora RC DroidBox; Jetibox Profi lze propojit s RC DroidBox přes Ji konektor a přenášet tak telemetrie do mobilního telefonu.

Postup aktivace EX výstupu pro připojení RC DroidBoxu k Jetiboxu Profi

- Zapněte JETIBOX profi



- Zmačkněte ESC: Hlavní menu




- Zvolte položku NASTAVENI



- Zvolte položku HLAUNI a Ji mode nastavte na hodnotu EX výstup



Zapojení RC DroidBoxu



Verze 1.21(Červenec 2017)

- Tato verze řeší problém s výpadky některých telemetrických hodnot.